



# SB05A IN-FRAME STORAGE DOOR

SB005-3065A


**1. Single bottle cage:** Storage Door can be oriented in either the low or high bottle cage position.




**2. Dual bottle cages:** Storage Door must be oriented in the high bottle cage position.



Choose preferred Storage Door orientation and install bottle cage using two lightly greased M5 x 16 mm fixing screws and optional 2.5 mm spacers for clearance purposes; two spacers maximum. Tighten to 2-3 N.m.




There are two sets of mounting holes, Upper (A) and Lower (B) to fine tune bottle cage location on the Storage Door.




2.5 mm Storage Door Bottle Cage Spacers SK-SB05-DR

● Grease



If no bottle cage is to be used, install the Storage Door Pull Tab. Tighten to 2-3 N.m.




Use up to a maximum of two SB05 spacers between the bottle cage and Storage Door to avoid any interference between the bottle cage and the frame during Storage Door installation or removal.

## ⚠ CAUTION

Not all bottle cages are compatible with the SB05A Storage Door. If the chosen bottle cage installed with up to two SB05 2.5 mm spacers contacts the down tube during Storage Door removal, that bottle cage may be considered incompatible with the Storage Door. Using an incompatible bottle cage may put the bottle cage, the frame (including paint), or the Storage Door at risk of damage, and may prevent the Storage Door from being removed from the frame.

Before Storage Door installation, clean frame around storage compartment with isopropyl alcohol. Apply adhesive frame protection film 6 mm above the upper edge and 6 mm below the lower edge of the storage compartment.



## Installation

1. Turn latch towards the unlock icon and fold open the Storage Door.
2. Insert upper hooked end of the Storage Door into the down tube storage compartment and slide upwards.
3. Insert lower hooked end into the down tube storage compartment and press down on the Storage Door until it clicks into place.
4. Finish by rotating the latch back to the top to lock.

## Removal

1. Turn latch towards the unlock icon.
2. If no bottle cage is mounted to the Storage Door, use the Pull Tab handle to pull upwards and remove the Storage Door from the frame.
3. If a bottle cage is installed, the cage can be used instead of the Pull Tab to removed the Storage Door.

### ⚠ CAUTION

Do not attempt to remove the Storage Door without using the included Pull Tab or a bottle cage. The edges of the Storage Door can be sharp and result in injury when attempting to pry the Storage Door from the frame.

